





№	Артикул	Наименование	К-во	№	Артикул	Наименование	К-во
1	R8CE-07B	E-retainer ring	1	26	R8186-692201	Clamp	1
2	PR8403-692201WA	Fan blade	1	27	R9PB30-18B	Straight slot elastic cylindrical	1
3	R8334-692203	Rubber nut	1	28	PR8081-691504-01	Connecting shaft	1
4	R8206-481001	Stator screw M4*55	2	29	PR8413-692204	Connecting wire	2
5	R8324-481001	Spring washer	2	30	PR9455-691501	Two-sided blown-sponge	1
6	R8321-481002	Flat gasket	2	31	PR8414-692203	PCB control panel	1
7	R8292-692202	Back holder	1	32	PR8044-692201RI	Switch trigger	1
8	R8BC-220807-ST03	608 bearing	1	33	R8342-692001	Compressed spring	1
9	PR8405-692203	Stator 230V/1000W	1	34	PR8042-522502	Switch	1
10	R8SJAB40-16B	Self tapping screw 4*16	12	35	DPR8422-692001	Power line	1
11	PR8006-692202SY+SB	Right housing	1	36	PR8411-522201	Terminal strip	1
12	PR8020-692204SB	Right cover	1	37	PR8184-520801WA	Cable clamp	1
13	PR8005-692201SB	Upper cover plate	1	38	R8SJAB40-14B	Self tapping screw 4*14	2
14	PR8402-692203	Rotor 230V/1000W	1	39	PR8332-532101-01	Power source sheath	1
15	RBC-261008-ST03	6000 bearing	1	40	DPR8341-692201	Rubber blanket	4
16	DPR8087-692201	Rubber column	1	41	PR8006-692201SY+SB	Left housing	1
17	R8292-692201	Front holder	1	42	PR8020-692203SB	Left cover	1
18	R8406-692201	Carbon brush	2	43	PR8312-692201RI	Pushing button	1
19	R8409-692203	Copper brush hold	2	44	PR8204-691301SB	Stop collar	1
20	PR8409-692201-01SB	Brush yoke	2	45	R8342-691302	Compressed spring	1
21	R8SIAN04-12B	Machine screw	7	001	PR9440-923145	P-Handle assy'	1
22	RBE-100608	Multiroll bearing	1	46	PR9003-923107-01	P-handle	1
23	R8081-692202	Gear shaft	1	47	R8SJGD05-20B	Screw M5*20	2
24	R8BC-240808-ST03	628 bearing	1	48	PR9186-923102	Fixed linking piece	1
25	R8334-692202	Shaft sleeve	1	49	R8NA-05B	Hex nut M5	2



№	Артикул	Наименование	К-во	№	Артикул	Наименование	К-во
50	R9204-691502D	Belt ring	1	73	R9123-903101	Bevel gear	1
51	R8SJGD05-08D	Screw M5*8	1	74	R9205-903101	Woodruff key	1
52	PR8440-692204SB	Back connecting tube	1	75	R9085-903101	Output shaft	1
007	L1112021	Front connecting tube assy'	1	76	R9BB-321509-ST03	Bearing	1
53	R8201-691101	Retainer ring	2	77	R8CA-22B	Retainer ring	1
54	R8RB03-03N	Rivet	1	78	R9334-903101	Shaft sleeve	1
55	R8324-691201	Reed	1	79	PR9200-903101	Oil seal	1
56	R9089-691501	Front tube soft shaft	1	006	PR8440-903116	Small shield Assembly.	1
57	R9066-691501	Screened pipe	1	80	PR8185-903104-03SB	Plastic small shield	1
58	R9087-691501	Front rod	1	81	R8SJGN05-12B	Combination screw	3
59	R8281-691508	Flexible shaft	1	83	8NA-06B	Self-locking nut	1
60	PR9065-903101	Connection	1	82	R9204-903101	Collar	1
002	PR9440-903108	Gear shaft assy'	1	003	PR8440-692205SB	Outer shield assy'	1
61	PR9065-903101	Hole card spring	1	84	R8CE-05B	E-retainer ring	3
62	R9BB-221006-ST03	Bearing	2	85	R8206-903101-01	Combination screw	3
63	R9202-903102	Washer	1	86	PR8185-691504SB	Outer hood	1
64	R9CD-10B	C-retainer ring	1	87	R8SJGD05-14B	Screw	2
65	R9123-903102	Bevel wheel	1	88	R9231-923101	Blade	1
66	R8SFHN05-30D	Combination screw	2	89	R8NG-05B	Self-locking nut	2
67	R8NG-05D	Self-locking nut	3	90	R8462-691501	Protect knife paper	1
68	R8SJGN05-12D	Combination screw	1	91	PR9454-903104	Blade sheath	1
69	R8208-903101	Sealing gasket	1	92	R9231-903101-01	Four teeth blade	1
70	R9SFDD08-10D	Outer hex head screw	1	93	R9186-903102	Blade clamp	1
71	R9146-903101U	Gear case	1	94	R8NG-10DL	Hex fange face screw	1
72	R9BB-260908-ST03	Bearing	1	95	R9PA14-20D	Cotter	1

