


101234090004

Diag.	Code		English Description	Qty.
2	25001001	排气口垫片	Exhaust gasket	1
3	25001100	机组消声器总成	Muffler assembly	1
3-2			Heat Shroud	1
5	LMB08		Flange hd hex. nut	2
10	LSB06012		Flange head bolt	4
11	TD06	弹垫06	Spring washer	4
12	PD06		Washer	4
13	25001004	消声器上支架	Muffler support A	1
14	LSB08020		Flange HD Hex. Bolt	1
15	TD08		Spring washer	1
16	PD08		Washer	1
17	25001005	消声器下支架	Muffler support B	1
18	LSB08020		Flange HD Hex. Bolt	1
19	TD08		Spring washer	1
20	PD08		Flat washer	1
21	LSB06012		Flange hd hex. bolt	1
22	TD08		Spring washer	1
23	PD08		Flat washer	1
24	25002001	160前端盖	Front cover	1
25	LSB08025		Flange hd hex. bolt	4
26	LSB05012		Tapping screw	2
27	25002002	电机风扇	Alternator fan	1
28	30002100	转子总成	Rotor	1
		压敏电阻	Varistor	1
		转子二极管	Diode	
29	25002003	球轴承	Ball bearing	1
30	PDC08	大平垫8	Washer	1
31	TDA08	弹垫08	Spring washer	1
32	LZA08230	Φ 160转子中心螺栓 (8.8级)	Hex. bolt	1
33	30002200	定子总成	Stator assembly	1
34	30002004	定子护罩 (Φ 160保护带)	Stator protector	1
35	25002005	160后端盖	Rear cover	1
36	LSB06145	固定后端盖法兰螺栓	Flange hd hex. bolt	4
37	25002300	AVR	AVR	1
37-1	25002006	碳刷	Carbon brush	1
37-2	LSB05012	法兰螺栓 M5*12	Flange hd hex. bolt	1
38	LSB05012	法兰螺栓 M5*12	Flange hd hex. bolt	2
42	LSB05012		Flange hd hex. bolt	1
42-2	TD08	弹垫05	Spring washer	1
45	25002400	接线柱	Terminal block	1
46	LSB05012	法兰螺栓 M5*12	Flange hd hex. bolt	2
47	25002007	160后端罩	End cover	1
48	LSB05012	法兰螺栓M5*12	Flange hd hex. bolt	2
49	25003100	LT3000CL圆管机架[331.7]芯110	Frame	1
50	LDA06012		Pan hd screw	4
51	LMA08	螺母M8	Hex. nut	4
52	TDA08	平垫8	Washer	4
53	25003200A	LT2500动力端减震垫	Shock absorber (engine)	4
	25003200B	LT2500电机端减震垫	Shock absorber (alternator)	
54	TDA08		Spring washer	8
55	LSB08045	法兰螺栓M8*45	Flange hd hex. bolt	2
56	LMA08		Flange hd hex. nut	4
58	25004001	油箱盖总成	Fuel tank cap	1
59	25004002		Seal for Cap	1
60	25004003	滤网	Fuel Strainer	1
61	25004100	油箱总成	Fuel tank ass'y	1
62	25004004	油标	Fuel float	1
63	25004005	指示器	Fuel level Indicator	1
63-2			Fuel indicator cover	1

63-3			Top gasket cover	1
63-4			Glass	1
63-5			Gasket for glass	1
64	LDA05010	螺钉M 5 *1 0	Countersunk hd screw	2
65	LSB06012	法兰螺栓	Flange hd hex. bolt	4
66	PDB06		Washer	4
67	25004006	衬套	Collar	4
68	25004007	邮箱减震垫	Rubber grommet	4
69	LMA06	螺母M6	Hex. nut	4
69-2			Washer	4
69-3			Lock washer	4
70	25004200	油开关组件	Fuel shut-off	1
70-2			Special nut	1
70-3			Rubber seal with flange	1
71	25004008	油管	Fuel pipe	1
72	25004009	油管夹	Clip	2
73		十字盘头机牙螺钉(4*12)	Special screw	4
74		电源指示灯	Power indicator light	1
75		波动开关 (红色, 特殊)	Engine on/off switch	1
76		交流电压表	Voltmeter	1
77		插座	Socket	1
78			Socket	1
79		接地总成	Ground terminal	1
80		接线柱 (正极)	DC positive terminal	1
81		接线柱 (负极)	DC negative terminal	1
82		保险丝	Fuse	1
83		断路器	Circuit breaker	1
84		面板后罩	Rear control panel cover	1
85		面板	Control panel ass'y	1
86	20001001	箱体	Crankcase	1
87	YF254106	油封	Oil seal	1
88	ZCA6205		Ball bearing	1
89	16001002	调速摆杆	Governor arm shaft	1
90	16001003	调速摆杆锁夹	Lock pin	1
91	16001004	垫片6	Washer	1
91-2		平垫圈	O-ring	1
92	LSB10015	放油螺塞	Drain plug	2
93	16001005	放油螺塞垫片	Drain plug washer	2
94	16001100	调速齿轮组件	Governor kit	1
94-2			Governor weight	2
94-3			Governor weight pins	2
94-4			Governor gear	1
95	16001006	调速轴	Governor shaft	1
96	16001007	调速轴卡簧	Governor shaft clip	1
97	16001008	调速推盘	Governor	1
98	16001004	垫片Φ6	Washer	2
100	16002001	曲轴箱盖	Crankcase cover	1
101	YF254106	油封25*41.25*6	Oil seal	1
102	ZCA6205		Ball bearing	1
103	16002002	带刻度机油尺	Oil filler cap	2
104	16002003	机油尺密封圈	Oil filler cap gasket	2
105	XA0814	定位销8*14	Sleeve	2
106	16002004	曲轴箱盖垫片	Case cover gasket	1
107	LSC080335	法兰螺栓M8*33.5	Flange hd hex. bolt	6
109	20003101	LT200曲轴V1	Crankshaft	1
110	16003102	正时齿轮	Timing driving gear	1
111	16003103	调速齿轮	Drive gear	1
	30001000	LT200V1	Engine LT200V1	
112	YJA0418	半圆键4*18	Woodruff key	1
113	16003200	连杆总成	Complete connecting rod	1
114	20003004	活塞	Piston	1

115	16003005	活塞销	Piston pin	1
116	16003006	活塞销卡簧	Piston pin clip	1
117	16003300	活塞环总成	Piston ring set	1
119	20004100	气缸盖组件	Cylinder head ass'y	1
119-2			Cylinder head	1
119-3			Intake valve guide	1
119-4			Exhaust valve guide	1
119-5			Valve guide clip	2
119-6			Intake valve seat	1
119-7			Exhaust valve seat	1
120	LZA08020	单机双头螺柱AM8*20	Threaded stud	2
121	16004007	单机双头螺柱	Threaded stud	2
121-2			Flange hd hex. nut	2
122	XA1016	定位销10*16	Sleeve	2
123	16004200	火花塞	Spark plug	1
124	16004001	气缸头密封垫	Cylinder head gasket	1
125	16004300	气缸盖罩总成	Head cover	1
126	16004002	气缸盖罩垫片	Head cover gasket	1
127	16004003	呼吸管	Breather tube	1
128	LSB06012	螺栓6*12	Flange hd hex. bolt	4
129	16004004	气缸头螺栓M8*60	Flange hd hex. bolt	3
129-2	16004004		Flange hd hex. bolt	1
130	16004005	下导风罩	Wind cover	1
131	LSB06012		Flange hd hex. bolt	2
132		火花塞扳手	Spark plug wrench	
133	20005100	凸轮轴总成	Camshaft assembly	1
134	20005001	气门挺柱	Valve pole	2
135	16005002	推杆	Push rod	2
136	16005003	推杆导板	Push rod guide plate	1
137	16005201	气门摇臂	Valve rocker	2
138	16005203	摇臂轴螺栓	Pivot nut	2
139	16005202	摇臂轴座销	Rocker pivot pin	2
140			Special Hex. nut	2
141	16005004	进气阀	Intake valve	1
142	16005005	排气阀	Exhaust valve	1
143	16005006	气门弹簧	Valve spring	2
144	16005007	进气门弹簧座	Intake valve spring seat	1
145	16005008	排气门弹簧座	Exhaust valve spring seat	1
146	16005009	排气门调节帽	Valve rotator	1
149	16006100	导风罩	Fan hood	1
150	LSB06012	法兰螺栓	Flange head hex. bolt	4
151	16006201	手拉盘外壳组件	Casing	1
	16006200	手拉盘总成	Recoil Ass'y	
152	16006202	蜗卷盘簧	Spiral spring	1
153	16006203	起动拉盘	Rope reel	1
154	16006204	棘爪弹簧	Ratchet spring	2
155	16006205	起动棘爪	Ratchet	2
156	16006206	摩擦弹簧	Friction spring	1
157	16006207	棘爪压板	Spring lid	1
158	16006208	压板轴位螺钉	Flanged retainer bolt	1
159	16006209	拉绳	Starter rope	1
160	16006210	拉手	Pull handle	1
161	LSB06008	小头法兰螺栓M6*8	Flange head hex. bolt	3
162	16006001	风扇后侧罩	Starter Shroud	1
163	LSB06012	法兰螺栓	Flange head hex bolt	1
164	16007001	空滤器垫片	Air cleaner gasket	1
165	16007002	化油器垫片	Carburetor gasket	1
166	16007003	机组化油器接块	Connecting block	1
167	16007004	进气口垫片	Inlet gasket	1
168	20007200	化油器总成	Carburetor assembly	1
168-A		负压阀	Negative pressure valve	1
168-B		双燃料调节阀固定板	Dual fuel valve fixed plate	1

168-2			Float chamber drain screw	2
168-3	16007102	浮子室放油螺钉垫片	Fiber washer	2
168-4	16007103	浮子室	Float chamber	1
168-5	16007104	浮子室密封垫	Float chamber gasket	1
168-6	16007105	浮子组合	Float	1
168-7			Choke butterfly	1
168-8			Idle adjustment screw	1
168-9			Mixture adjustment screw	1
169-2			Spring for mixture adjustment	1
169-3			Throttle unit	1
169-6		化油器阻风门手柄	Choke switch	1
170	16008200	空滤总成	Air filter assembly	1
170-2			Air filter housing	1
170-3			Filter element housing	1
170-4			Air filter cover	1
170-5			Flange hd hex. bolt	4
170-6			Air filter clamps	2
170-7			Air filter housing seal	1
171	16008107	空滤器滤芯	Air filter element	1
		空滤器后盖(机组)	Air Filter cover	
173	16009200	机组调速控制组件	Speed control assembly	1
173-2			Speed support assembly	1
173-3			Pan head screw	1
173-4			Control adjust spring	1
173-5			Control pull spring	1
174	LSB06012		Flange hd hex. bolt	2
175	16009001	调速拉杆	Governor rod	1
176	16009002	节气门复位弹簧	Throttle return spring	1
177	16009003	调速弹簧	Governor spring	1
178	16009004	调速臂	Regulating arm	1
179	16009005	调速臂螺栓M6*21	Governor arm bolt	1
180	LMB06		Flange bolt	1
187	16012100	飞轮组件	Fly wheel	1
188	16012001	冷却风叶	Cooling fan	1
189	16012002	起动机	Starter pulley	1
190	16012003	飞轮螺母M14X1.5	Fly wheel nut	1
191	16012004	一体化点火线圈	Ignition coil	1
192	LSB06028		Flange hd hex. bolt	2
193	16012005	机油油位传感器组件	Oil sensor	1
194	LSB06014	法兰螺栓M6*14	Flange hd hex. bolt	2
195	LMB10		Special nut	1
196	16012007	单向导通阀	Diode	1
197	KBPC3506	整流桥	Diode Bridge	1



168-B



