


UP168-I(UP160)零部件配置表


1. 曲轴箱总成 CRANKCASE ASSY



序号	编号		英文名称	数量	
	CODE		DESCRIPTION	QTY.	
1	3A1001001		Drain plug	2	
2	3A1001002		Washer,drain plug	2	
3	3S61254108		Oil seal, crankshaft	2	
4	3A2201004		Crankcase	1	
5	3A2001005		Regulating sway bar	1	
6	3A2001006		Washer	2	
7	3A2001007		Split pin	1	
8	3A2001008		Regulating shaft	1	
9	3A2001009		Snap ring	1	
10	3A2001100		Driven gear assy	1	
11	3A2001200		Dipstick with seal	2	
	3A2001200A		Dipstick with seal		
12	3A2001012		Crankcase cover	1	
13	3A2001013		Gasket, crankcase	1	
14	3S7106205		Bearing 6205	2	
15	3S5108014		Set pinΦ8×14	2	
16	3S22080331		Bolt M8×33.5	6	

UP168-I(UP160)零部件配置表

2. 气缸盖、气缸盖罩总成 CYLINDER HEAD & CYLINDER HEAD COVER ASSY




序号	编 号	英文名称	数 量	
	CODE	DESCRIPTION	QTY.	
1	3S22060121	Bolt M6×12	6	
2	3A2002100	Cylinder head cover	1	
3	3A2002006	Gasket,cyl. head cover	1	
4	3A2002200	Valve rocket assy	1(2 units)	
5	3A2002008	Push guide	1	
6	3A2002009	Cap	1	
7	3A2002010	Exhaust spring seat	1	
8	3A2002011	Intake spring seat	1	
9	3A2002012	Valve spring	2	
10	3S22080601	Bolt M8×60	4	
11	3S25080341	Stud AM8×34	2	
12	3A2202017	Cylinder head assy	1	
13	3A2202018	Cylinder head gasket	1	
14	XA010016	Set pin	2	
15	3A2202019	Exhaust valve	1	
16	3A2202020	Intake valve	1	
17	3A2002022	Tappet	2	
18	3A2002023	Pusher	2	
19	3S25061051	Stud AM6×105	2	
20	3A2002024	Lead wind cover	1	
21	3A2002026	Oil seal, pipe	1	
22	3A2002027	Nylon, lining	2	

UP168-I(UP160)零部件配置表

3. 曲轴、活塞连杆、凸轮轴总成、飞轮组件


CRANKSHAFT, PISTON, CONNECTING, CAMSHAFT ASSY & FLYWHEEL ASSY



序号	编 号	英文名称	数 量		
	CODE	DESCRIPTION	QTY.		
1	3A2203100	Piston ring set	1		
2	3A2003002	Piston pin circlip	2		
3	3A2203003	piston	1		
4	3A2003004	Piston pin	1		
5	3A2003200	Connect rod assy	1		
6	3A2003300	Cranshaft assy	1		
7	3A2003400	Camshaft assy	1		
	3A2003400A	Camshaft assy			
8	3A2003008	Flywheel	1		
9	3A2003009	Flywheel fan	1		
10	3A2003010A	Starting flange	1		
11	3A2003011	Nut M14×1.5	1		

UP168-I(UP160)零部件配置表


4. 反冲起动器部件 点火线圈组件
RECOIL STARTER & IGNITION COIL ASSY



序号	编 号	英文名称	数 量		
	CODE	DESCRIPTION	QTY.		
1	3A2004001	Engine switch	1		
2	3A2004002	Fan hood	1		
	3A2004002C	Fan hood			
3	3S22060121	Bolt M6×12	5		
4	3S22060081	Bolt M6×8	4		
	3A2004100Q	Recoil starter assy			
6	3A2004007	Shroud comp.	1		
	3A2004007A	Shroud comp.			
	3A2004007B	Shroud comp.			
7	3A2004008	Diode	1		
8	3A2004200	Oil sensor	1		
9	3S22060141	Bolt M6×14	2		
10	3S22060221	Bolt M6×22	2		
11	3A2004300	Ignition coil assy	1		
12	3A2004013	Spark plug F6RTC	1		

UP168-I(UP160)零部件配置表


5. 空气滤清器总成
AIR CLEANER ASSY



序号	编 号		英文名称	数 量	
	CODE		DESCRIPTION	QTY.	
1	3A2005100C		Air cleaner assy	1	
2	3S12061		Nut M6	2	
3	3A1005004A		Air duck	1	
	012021000101			1	

UP168-I(UP160)零部件配置表

6. 燃油供油系统
FUEL SUPPLY SYSTEM




序号	编号			英文名称	数量	
	CODE			DESCRIPTION	QTY.	
1	3A2006001	3A2006001		Pipe clamp	2	
2	3B0111007	3B0111007		Fuel pipe	Φ4.5×170mm	
3	3A2006010	3A2006010		Inlet gasket	1	
4	3A2006011	3A2006011		Connecting block	1	
5	3A2006012	3A2006012		Carburetor gasket	1	
6	3A2206200A	3A2006200A		Carburetor assy	1	
7	3A2006014	3A2006014		Gasket,air cleaner	1	
8	3A2006300B	3A2006300B		Regulating control assy	1	
9	3A2006016A	3A2006016A		Back spring	1	
10	3A2006017	3A2006017		Regulating spring	1	
11	3A2006018	3A2006018		Pulling rod	1	
	3A2006019A	3A2006019A		Lock bolt		
13	3A2006020	3A2006020		Regulating arm	1	
14	3S12061	3S12061		Nut M6	1	

UP168-I(UP160)零部件配置表

7. 起动机及发电机系统

STARTER & GENERATOR ASSEMBLY



序号	编 号		英文名称	数 量	
	CODE		DESCRIPTION	QTY.	
1	3A2007100		Starting motor assy	1	
2	3S22060281		Bolt M6×28	1	
3	3S22060322		Bolt M6×32	1	
4	3A2201004		Crankcase	1	
5	3A2007200		Charge coil	1	
6	3S22060352		Bolt M6×35	2	
7	3A2007007		Clamper, cord	1	
8	3S22060121		Bolt M6×12	2	
9	3A2007300		Flywheel	1	